

kaise

INSTRUCTION MANUAL

AC/DC DIGITAL CLAMP METER

SK-7718
SK-7719

KAISE CORPORATION

422 Hayashinogo, Ueda City, Nagano Pref.,
386-0156, Japan

TELEPHONE : +81-268-35-1600(REP.)

FAX : +81-268-35-1603

E-mail : sales@kaise.com


http://www.kaise.com

Product specifications and appearance are subject to change without notice
due to continual improvements.




1201-7718-4 1408

KAISE CORPORATION

FOR SAFETY MEASUREMENTS

Prior to use, to avoid an electrical shock hazard to the operator and/or damage to the instruments, read carefully the WARNINGS with the symbol  listed in 「4. SAFETY PRECAUTIONS」, 「5. MEASUREMENT PROCEDURES」 and 「6. MAINTENANCE」 of this instruction manual.

Important Symbol

-  The symbol listed in IEC 61010-1 and ISO 3864 means "Caution (refer to instruction manual)".
-  **WARNING** : The symbol in this manual advises the user of an electrical shock hazard that could result in serious injury or even death.
-  **CAUTION** : The symbol in this manual advises the user of an electrical shock hazard that could cause injury or material damages.

WARNING

High Power Line is very dangerous and/or lethal to measure. High Power Line sometimes includes High Surge Voltage that could possibly induce dangerous arcs of explosive short in the instrument and could result in serious injury to the operator. When measuring dangerous voltages of High Power Line or High Voltage Circuit, always place the instrument away from your body without holding it with your hands. Do not touch the Clamp Meter, its Test Leads, or any part of the circuit while it is on.

CONTENTS

| | |
|---|----|
| 1. INTRODUCTION | 2 |
| 1-1. GENERAL | 2 |
| 1-2. FEATURE | 2 |
| 1-3. UNPACKING AND INSPECTION | 2 |
| 2. SPECIFICATIONS | 3 |
| 2-1. GENERAL SPECIFICATIONS | 3 |
| 2-2. MEASUREMENT SPECIFICATIONS | 4 |
| 3. NAME ILLUSTRATION | 7 |
| 4. SAFETY PRECAUTIONS | 12 |
| 4-1. WARNINGS | 12 |
| 4-2. GENERAL WARNINGS AND CAUTIONS | 17 |
| 5. MEASUREMENT PROCEDURES | 17 |
| 5-1. PREPARATION FOR USE | 17 |
| 5-2. CURRENT (\bar{A} , \tilde{A} , Hz) MEASUREMENTS | 20 |
| 5-3. VOLTAGE (\bar{V} , \tilde{V} , Hz, %) MEASUREMENTS | 21 |
| 5-4. RESISTANCE (Ω) MEASUREMENTS | 23 |
| 5-5. CONTINUITY (\cdot) TESTS | 24 |
| 5-6. DIODE (\rightarrow) TESTS | 25 |
| 5-7. CAPACITANCE (F) MEASUREMENTS | 27 |
| 6. MAINTENANCE | 28 |
| 6-1. WARRANTY STATEMENT | 28 |
| 6-2. BATTERY REPLACEMENT | 28 |
| 6-3. PERIODICAL CHECK AND CALIBRATION | 30 |
| 6-4. REPAIR | 30 |

1. INTRODUCTION

1-1. GENERAL

SK-7718/7719 are micro-computer controlled, most compact and all-purpose AC/DC Digital Clamp Meters. They are provided with easy to read 4000 count LCD and can measure 1000A AC/DC with Advanced Testing Functions such as Peak Hold (SK-7718 only), Max/Min, etc, which are very useful for testing and maintaining multifarious electric appliances/apparatus and equipments/facilities. They are also designed with usability in mind for checking electric systems of motorcars. The reliable and tough instruments, SK-7718/7719 ensure accurate measurements with every target.

1-2. FEATURES

1. AC/DC 1000A MEASUREMENTS

Provided with AC/DC 1000A, AC/DC 600V, 40MΩ, \cdot , \cdot and \cdot measurements, SK-7718/7719 present versatility.

2. ADVANCED TESTING FUNCTIONS

Peak Hold (SK-7718 only) Max/Min and Difference measurements are available as well as Display Hold.

3. Easy Use and Reading

Handy compact body and 4000 count LCD with units and symbols.

4. DUST - PROOF AND WATER - RESISTANT CASES

Both models are designed of Dust-proof and Water-resistant to protect PCB and switches. But not with Clamp Head.

5. SAFETY DESIGN

Designed with user's safety in mind, CE Mark is approved complied with EMC and LVD (IEC 61010-1).

6. AUTO POWER OFF

Power is automatically turned off after about 12 minutes of power on. Battery Consumption is prevented when power-off is forgot.

1-3. UNPACKING AND INSPECTION

Before unpacking, examine the shipping carton for any sign of damage. Unpack and inspect the instrument and accessories for

13. CONTINUITY TEST : buzzer sounds in case less than approx. 50Ω

14. OVERLOAD PROTECTION :

- Current ; \sim / \equiv 1500A rms (600V Line) for one minute
- Voltage ; \sim / \equiv 900V rms for one minute
- Resistance ; \sim / \equiv 300V rms for one minute

15. DIELECTRIC STRENGTH : 5.55 kV (Sine Wave) for one minute between Case and Input Terminals

16. OPERATING TEMP. & HUMID.: 0°C to 40°C, less than 80% in non-condensing

17. STORAGE TEMP. & HUMID.: -20°C to 60°C, less than 70% in non-condensing

18. TEMPERATURE COEFFICIENT: When 0°C to 18°C and 28°C to 40°C, (Accuracy on condition of 23°C \pm 5°C) \times 0.1/%

19. SAFETY LEVEL : CE Mark authorized. IEC 61010-1 Overvoltage Category III 600V and EMC Test passed

20. POWER SUPPLY : 9V 6F22 (S-006P) \times 1

21. POWER CONSUMPTION :

SK-7718 : Less than 90mW, approx. 25 hours continuous operation
SK-7719 : Less than 75mW, approx. 29 hours continuous operation

22. AUTO POWER OFF : LCD is automatically turned off under power off condition after 12 minutes of power on

23. CONDUCTOR DIAMETER : 35mm ϕ

24. DIMENSIONS & WEIGHT : 193 \times 60 \times 34.5mm, 300g

25. OPTIONAL ACCESSORIES : 880 Line Separator, 940 Alligator Clips
100-41 Test Lead Kit, 100-62 Test Lead Set, 948 Alligator Clips,
793 Coil-Type Contact Pin

2-2. MEASUREMENT SPECIFICATIONS (23°C \pm 5°C, less than 80% RH)

1. Current Measurements ($\bar{A} / \tilde{A} \rightarrow \text{Hz} \rightarrow$)

1-1. DC Current (\equiv A)

| Range | Resolution | Accuracy | Max. Input Current |
|--------|------------|---|--------------------|
| 400.0A | 0.1A | $\pm 1.5\% \text{rdg} \pm 3 \text{dgt}$ | 400A DC |
| 1000 A | 1 A | 400~600A : $\pm 1.5\% \text{rdg} \pm 3 \text{dgt}$ 601~1000A : $\pm 3.0\% \text{rdg} \pm 3 \text{dgt}$ | 1000A DC |

* Range Selection (Manual-ranging) : SK-7719 only

1-2. AC Current (\sim A)

SK-7718: True RMS (AC Coupling)
SK-7719: Average Rectification

| Range | Resolution | Accuracy (50/60Hz) | Max. Input Current |
|--------|------------|---|--------------------|
| 400.0A | 0.1A | $\pm 1.5\% \text{rdg} \pm 5 \text{dgt}$ | 400A rms |
| 1000 A | 1 A | 400~600A : $\pm 1.5\% \text{rdg} \pm 5 \text{dgt}$ 601~1000A : $\pm 3.0\% \text{rdg} \pm 5 \text{dgt}$ | 1000A rms |

any damage from mechanical shock, water leakage, or other causes. If any damage or missing item is found, consult the local dealer for replacement.

Make certain that following items are included in the box.

- Digital Clamp Meter
- One pair of Test Leads (100-57 complies with IEC spec.)
- One 9V 6F22 Battery
- Instruction Manual
- 1012 Carrying Case

2. SPECIFICATIONS

2-1. GENERAL SPECIFICATIONS

1. DISPLAY:

- Numerical Display ; 4000 Count LCD, Max 9999, 12mm high.
- Units and Symbols ; A, mV, V, Hz, kHz, %, Ω , k Ω , M Ω , \cdot , \cdot , \cdot , nF, μ F, \equiv , \sim , \cdot , BAT, AUTO, PH (SK-7718), DIFF, DH, MAX, MIN, OL and decimal point

2. OPERATING PRINCIPLE : $\Sigma \Delta$ Conversion

- MEASURING PRINCIPLE : SK-7718 : True RMS (AC Coupling)
SK-7719 : Average Rectification

4. SAMPLING RATE : 3 times/sec.

5. RANGE SELECTION : SK-7718 : Autoranging

SK-7719 : Autoranging and Manual-ranging

6. POLARITY: Autopolarity, \cdot symbol when minus, \cdot symbol is implied

7. OVERLOAD INDICATION : OL symbol is shown. (excluding AC/DC 600V, 1000A ranges)

8. BATTERY WARNING : BAT symbol is shown

9. DISPLAY HOLD : Display is held by DH Key

10. MAX/MIN : Maximum and Minimum Values are measured by MAX/MIN Key on \bar{A} , \tilde{A} , \tilde{V} , \tilde{V} and Ω

11. PEAK HOLD (SK-7718 only) : Up to \equiv / \sim 1500A, 1000V peak Peak Value is measured at 10m Sec. in PH Mode

12. DIFF (Difference) : Desired value being measured is stored and converted to read zero on LCD and only difference is shown with proceeding measurements.

Also use this Key to take zero on DC Current or Peak Hold measurements only when necessary.

* Range Selection (Manual-ranging) : SK-7719 only

* Crestfactor : 400A less than 3, 1000A less than 1.5 (SK-7718 only)

* Accuracy : 40~400Hz ; add 1.5%rdg.

1-3. Frequency (Hz)

| Range | Accuracy | Resolution | Input Sensitivity |
|-------------------|---|------------|-------------------|
| 1.000Hz~4.999Hz | $\pm 0.2\% \text{rdg} \pm 2 \text{dgt}$ | 1m Hz | 5A rms |
| 5.00Hz~49.99Hz | | 10m Hz | |
| 50.0Hz~499.9Hz | | 100m Hz | |
| 0.500kHz~1.000kHz | | 1 Hz | |

* Max. Input 1000A rms * Autoranging only

1-4. Peak Hold (\approx 1500A)

SK-7718 only

| Range | Resolution | Accuracy (Pulse width:10ms) | Max. Input |
|--------|------------|---|------------|
| 1000 A | 1 A | $\pm 5.0\% \text{rdg} \pm 5 \text{dgt}$ | 1500A |

* Less than 50A is not specified. * 2 to 3 digits remain.

2. Voltage Measurements ($\bar{V} / \tilde{V} \rightarrow \text{Hz} \rightarrow \% \rightarrow$)

2-1. DC Voltage (\equiv V)

| Range | Accuracy | Resolution | Input Resistance | Max. Input Voltage |
|---------|---|------------|-----------------------------|--------------------|
| 400.0mV | $\pm 1.0\% \text{rdg} \pm 3 \text{dgt}$ | 0.1mV | $\geq 100 \text{M}\Omega$ | 600V DC |
| 4.000 V | | 1mV | $\approx 11 \text{M}\Omega$ | |
| 40.00 V | | 10mV | $\approx 10 \text{M}\Omega$ | |
| 400.0 V | | 100mV | | |
| 600 V | | 1V | | |

* Range Selection (Manual-ranging) : SK-7719 only

2-2. AC Voltage (\sim V)

SK-7718: True RMS (AC Coupling)
SK-7719: Average Rectification

| Range | Accuracy | Resolution | Input Resistance | Max. Input Voltage |
|---------|---|------------|-----------------------------|--------------------|
| 4.000 V | $\pm 1.0\% \text{rdg} \pm 5 \text{dgt}$ (40~400Hz) | 1 mV | $\approx 11 \text{M}\Omega$ | 600V rms |
| 40.00 V | | 10 mV | $\approx 10 \text{M}\Omega$ | |
| 400.0 V | | 100 mV | | |
| 600 V | | 1 V | | |

* Range Selection (Manual-ranging) : SK-7719 only

* Crestfactor : 400V less than 3, 600V less than 2 (SK-7718 only)

* Accuracy : 40~400Hz ; add 1.5%rdg.

2-3. Frequency (Hz)

| Range | Accuracy | Resolution | Input Sensitivity |
|-------------------|---------------|------------|-------------------|
| 1.000Hz~4.999Hz | ±0.2%rdg±2dgt | 1 mHz | 5V rms |
| 5.00Hz~49.99Hz | | 10 mHz | |
| 50.0Hz~499.9Hz | | 100mHz | |
| 0.500kHz~4.999kHz | | 1 Hz | |
| 5.00kHz~49.99kHz | | 10 Hz | |

*Max.Input 300V rms *Autoranging only

2-4. Duty Cycle (%)

| Range | Accuracy | Resolution | Input Sensitivity | Max. Input |
|---------|---------------|------------|-------------------|------------|
| 10%~90% | ±2.0%rdg±2dgt | 0.1% | 3V (square wave) | 300V rms |

*Frequency Range : 1Hz~1kHz

2-5. Peak Hold (≈1000V)

SK-7718 only

| Range | Resolution | Accuracy (Pulse width:10ms) | Max. Input |
|-------|------------|-----------------------------|------------|
| 600 V | 1 V | ±5.0%rdg±5dgt | 1000V |

3. Resistance (Ω)

| Range | Accuracy | Resolution | Measurement Current | Open Circuit Voltage |
|----------|---------------|------------|---------------------|----------------------|
| 400.0 Ω | ±1.5%rdg±5dgt | 0.1Ω | ≤0.3mA | ≈0.4V |
| 4.000 kΩ | ±1.0%rdg±3dgt | 1 Ω | ≤40 μA | |
| 40.00 kΩ | | 10Ω | ≤4 μA | |
| 400.0 kΩ | 100Ω | ≤0.4 μA | | |
| 4.000 MΩ | ±4.0%rdg±5dgt | 1kΩ | ≤40 nA | |
| 40.00 MΩ | ±6.0%rdg±5dgt | 10kΩ | | |

*Overload Protection : 300V rms 1minute

*Range Selection (Manual-ranging) : SK-7719 only

4. Continuity (·||)

| Range | Buzzer | Resolution | Measurement Current | Open Circuit Voltage |
|--------|--------|------------|---------------------|----------------------|
| 400.0Ω | ≤50Ω | 0.1Ω | ≤0.4mA | ≈0.44V |

*Overload Protection : 300V rms 1minute

5. Diode Tests (⇄)

| Range | Accuracy | Resolution | Open Circuit Voltage | Overload Protection |
|--------|---------------|------------|----------------------|---------------------|
| 0~1.5V | ±5.0%rdg±5dgt | 1mV | ≤1.7V | 300V rms 1minute |


6. Capacitance (-||-)

| Range | Accuracy | Resolution | Open Circuit Voltage | Overload Protection |
|----------|----------------|------------|----------------------|---------------------|
| 50.00 nF | ±5.0%rdg±10dgt | 10pF | ≤1.7V | 300V rms 1minute |
| 500.0 nF | | 100pF | | |
| 5.000 μF | | 1nF | | |
| 50.00 μF | | 10nF | | |
| 100.0 μF | | 100nF | | |

*Autoranging only

3. NAME ILLUSTRATION

SK-7718



SK-7719




Fig. 1

1. FUNCTION Switch

Set FUNCTION Switch to a desired position, A, V or Ω and set it to OFF position when measurements are finished.

2. SHIFT Key : ⇄ → Hz → % , Ω → ·|| → ⇄ → -||-

Press this Key to select Hz in Current Measurement, Hz and % in Voltage Measurement, and to select Ω, ·||, ⇄, and -||- Measurement.

NOTE: When continuous measurements more than 10 minutes are necessary, set Function Switch to A, V or Ω position with SHIFT Key pressed on for less than one second.

NOTE: APO symbol is not displayed on LCD and Auto Power Off does not work during measurements.

3. PH Key : Peak Value Measurement up to ⇄ / ~1500A, 1000V (SK-7718 only)

- Clamp Head is placed away from conductor and Input is zero.
- Under this condition, press PH Key for more than 1 second. About 2A to 3A and PH symbol are shown on LCD.
- Open Clamp Head and clamp on a single conductor and read Peak Value on LCD.
- Remove Clamp Head from the conductor and press PH Key for more than 1 second. PH symbol disappears and PH Key is canceled.


4. DH Key : Display Hold

Press this Key for less than 0.5 second. DH symbol is shown and display is held. To cancel this Key, press it again.

5. DIFF Key : Difference Measurements

DIFF Key is used to make Difference Measurements. When measuring a value or applying a desired value into the instrument, press DIFF Key for more than 1 sec and the input value is stored and converted to read 0±1 digit on LCD with DIFF symbol displayed. The difference between the stored value and a measuring value is displayed on LCD with preceding measurements. To cancel DIFF Key, press DIFF Key for more than 1 second.

NOTE: When DIFF Key is on, DH Key or MAX/MIN Key can work.
NOTE: The Maximum input Values are the same even when DIFF Key is on, do not make measurements that will exceed the maximum input values.



6. MAX / MIN Key

a. Max / Min Measurements

Press MAX/MIN Key once when measuring. For SK-7719, keep pressing this Key for one second or more. MAX MIN symbol appears on LCD and MAX/MIN measurement starts.

To cancel MAX/MIN Key, press MAX/MIN Key for more than 1 second.

NOTE: AUTO POWER OFF Function does not work when MAX/MIN Key is on.

b. Max / Min Measurements + Display Hold

When measuring MAX/MIN value, press DH Key to hold the value.

NOTE: To cancel DH Key, press DH Key again.

7. RANGE Key (Range Selection : SK-7719 only)

Press RANGE Key to select Manual-ranging for current, voltage or resistance measurements.

The default setting when turning on the power is Autoranging with "AUTO" indication on LCD. In Manual-ranging, this symbol disappears and necessary measurement ranges are selectable in the following ways.

1. Press RANGE Key before measurement. Decimal point moves to the next digit by pressing this key. Confirm the decimal point position and select the necessary range.
2. Press RANGE Key during Autoranging measurement. The range under measurement is held.

To cancel Manual-ranging and go back to Autoranging, press RANGE Key again for 1 second or more until "AUTO" symbol appears on LCD.

- 10 -

10. SAFETY LIMIT Indicator

The line to protect yourself against electrical shock hazard. Do not put your fingers over this line while current measurement.

11. Input Terminals

To measure DC/AC Voltage, insert Test Plugs of Test Leads into COM and V Terminals. To measure Ω , \cdot), \cdot), \cdot), \cdot), insert Test Plugs into COM and Ω , \cdot), \cdot), \cdot), \cdot), Terminals.

⚠ WARNING : INPUT Terminals are not used to measure Current. For safety, remove Test Leads from INPUT Terminals when measuring Current.

⚠ WARNING : Risk of Electric Shock exists on the Terminal marked with **⚠** when voltage is being measured on COM and V Terminals.

4. SAFETY PRECAUTIONS

Correct knowledge about electric measurements is necessary because electric measurement is sometimes a very dangerous work. To eliminate possibility of injury to the operator and damage to the instrument, the following precautions and measurement procedures must be taken. Misuse, abuse and carelessness cannot be prevented by any written word and is fully the operator's responsibility. Observing the following precautions, take safe measurements.

4-1. WARNINGS

⚠ WARNING 1. Checks of Body and Test Leads

Before every measurement, do not fail to confirm that Body of this instrument and handle insulators of the attached Test Leads have no cracks nor any other damage on them. Make sure that the body and the handle insulators are free of dust, grease and moisture.

- 12 -

8. LCD




Fig. 2

| | |
|------------------------------------|--|
| AUTO | : Autoranging |
| BAT | : Battery Warning |
| --- | : Direct Current (DC) on Current and Voltage |
| - | : Minus symbol automatically shown when polarity is minus. |
| ~ | : Alternating Current (AC) on Current and Voltage |
| APO | : Auto Power Off |
| DH | : Display Hold |
| PH | : Peak Hold (SK-7718 only) |
| DIFF | : Difference Measurements |
| MAX/MIN | : Max/Min measurements go on. Measuring Value then is shown. |
| MAX | : Maximum Value |
| MIN | : Minimum Value |
| ···) | : Continuity test |
| ⇄ | : Diode Test |
| mV, V | : Units of Voltage |
| Ω , k Ω , M Ω | : Unit of Resistance |
| A | : Unit of Current |
| Hz | : Frequency |
| % | : Duty Cycle |
| ⇄ | : Capacitance |

9. CLAMP HEAD

Open CLAMP HEAD and clamp on a single conductor. When measuring DC current, make sure of the polarity so that the current should flow in the conductor from Front Case (+) to Rear Case (-) according to the \Rightarrow (arrow) mark on the CLAMP HEAD.

NOTE : If two or three conductors are clamped into CLAMP HEAD at a time, the measurement becomes impossible.

- 11 -




Fig. 3

⚠ WARNING 2. Warning for High Power Line Measurements

High Power Lines (High Energy Circuits) such as Distribution Transformers, Bus Bars, Large Motors, etc. are very dangerous. High Power Line sometimes includes High Surge Voltage that could induce explosive short in the instrument and could result in shock hazard. When measuring voltage of High Power Line, do not touch the Clamp Meter, its Test Leads or any part of the Circuit while it is on.

⚠ WARNING 3. Warning for High Voltage Measurements

Even if with Low Energy Circuits of electric/electronic appliances, heating elements, small motors, line cords and plugs, etc., High Voltage Measurements are very dangerous. Do not touch the Clamp Meter, its Test Leads or any part of the Circuit while it is on. Generally, shock hazard shall be considered to exist at any part involving a potential in excess of 30V rms or 42.4V DC or peak and where a leakage current from that part to ground exceeds 0.5mA.

⚠ WARNING 4. Dangerous Voltage Measurement Procedure

Always observe strictly the following measurement procedure when measuring dangerous voltage.

1. Before measurement, turn off power to the circuit to be measured.
2. Insert Black Test Plug of Test Leads into COM Terminal and Red Test Plug of Test Leads into V Terminal.

- 13 -

3. TEST LEADS

Always use Test Leads that complies with IEC specifications (IEC 61010-031 and 600V~) for safety.

Insert Black Test Plug of Test Leads into COM terminal and Red Test Plug of Test Leads into V or Ω/\sim Terminal. Test Prods of Test Leads are connected to the circuit to be measured.

It is good practice to use Black Test Lead for COM Terminal (- polarity) and Red Test Lead for V or Ω/\sim Terminal (+ polarity).

4. FUNCTION Switch

Set FUNCTION Switch to desired position and make certain that all display segments appear for one second.

NOTE: If the display does not appear or BAT symbol appears when FUNCTION Switch is set to desired position, the battery may be consumed.

NOTE: Make certain that DH Key is not pressed ON. If DH Key is operative, measurements can not be performed.

5. AUTO POWER OFF

After about 12 minutes of last operation of FUNCTION Switch or the other Keys, power turns off automatically (goes down in sleep condition and 0.01mW consumption) with LCD displayed off. This function prevents battery consumption when power off is forgotten.

NOTE: To cancel AUTO POWER OFF to make continuous measurements longer than 10 minutes, set Function Switch to desired position with pressing SHIFT Key for less than 1 second.

NOTE: Also AUTO POWER OFF does not work when MAX/ MIN Key is on. Therefore, continuous measurements longer than 10 minutes can be made with MAX/MIN Key pressed on.

- 18 -

\perp : Earth (Ground)

\square : Double Insulation

5-2. CURRENT (\bar{A} , \tilde{A} , Hz) MEASUREMENTS

\triangle WARNING

Maximum Input Current of AC/DC Current Function is 1000A (600V line). Do not attempt to measure any current that might exceed 1000A AC/DC. Prior to measurements, read carefully 「4. SAFETY PRECAUTIONS」 of this instruction manual to avoid electrical shock hazard and/or damage to the instrument.

1. Set FUNCTION Switch to desired \bar{A} or \tilde{A} position. On \tilde{A} position, LCD shows random digits. But this does not affect the specified accuracy.

\triangle WARNING

Test Leads are not required for Current Measurements. For safety measurements, remove Test Leads from INPUT Terminals. Do not touch any part of the Power Line or the Circuit while it is on.

2. Open CLAMP HEAD and clamp on a single conductor.
NOTE: If two or three conductors are clamped on at a time, the measurement cannot be made.
NOTE: In case of measuring DC current, clamp on the conductor with Front Case faced to + polarity.
3. Read the current on LCD.
4. Hz : Press SHIFT Key while \bar{A} or \tilde{A} measurements.
5. Display Hold, Difference, Max/Min, Peak Hold (SK-7718 only) and Range Selection (SK-7719 only) are available. Refer to DH Key, DIFF Key, MAX/MIN Key, PH Key and RANGE Key on page 8 to 10. In PH Mode, 2A to 3A remain.
6. When measurements are finished, remove CLAMP HEAD from the circuit and set FUNCTION Switch to OFF position.

- 20 -

6. POWER-ON INITIALIZE (for DC Current measurement)

The instrument performs POWER-ON INITIALIZE automatically when turning on the power.

This function is effective when turning on the power without any inputs. If any inputs are applied to the instruments, it does not work correctly. LCD will display 0±1 digit when INITIALIZE was done correctly. If LCD does not display it, turn the power on again or press DIFF Key.

NOTE: INITIALIZE sometimes does not work correctly due to some CPU error even if no inputs are applied. If LCD displays 3 digits or more, use DIFF Key.

NOTE: For current measurements near the high current conductor, INITIALIZE does not work correctly. In this case, take the instruments away from the conductor, and turn the power on again.

7. OVERLOAD INDICATION

For Current and Voltage measurements, "OL" symbol IS NOT displayed on LCD even if the measured values exceed their maximum input values, 1000A AC/DC or 600V AC/DC.

\triangle WARNING

Do not attempt to make any measurements that might exceed the maximum value of the function being used to avoid electrical shock hazard and/or damage to the instrument.

8. SYMBOL MARK

The following symbols shown on the instrument and in the instruction manual are listed in IEC 61010-1 and ISO 3864.

\triangle : Warning or Caution (refer to instruction manual.)

\triangle : Warning, risk of electric shock

--- : Direct Current (DC)

\sim : Alternating Current (AC)

--- : DC and AC

- 19 -




Fig. 8

5-3. VOLTAGE (\bar{V} , \tilde{V} , Hz , %) MEASUREMENTS

\triangle WARNING

Maximum Input Voltage of V function is 600V. Do not attempt to measure voltage that might exceed 600V. Prior to measurements, read carefully 「4. SAFETY PRECAUTIONS」 of this instruction manual to avoid electrical shock hazard and/or damage to the instrument.

1. Insert Black Test Plug into COM Terminal and Red Test Plug into V . Hz . % Terminal.
2. Set FUNCTION Switch to desired \bar{V} or \tilde{V} position. Random digits are shown LCD. But, this does not affect the specified accuracy.
3. Connect Black Test Prod to the negative (earth) side of the circuit being measured and Red Test Prod to the positive (high potential) side of the circuit.

- 21 -

NOTE : When taking voltage measurements, always connect the instrument **IN PARALLEL** with the circuit being measured.

⚠ WARNING

When measuring dangerous voltage more than 220V, turn off power to the circuit to be measured and connect Test Prods to the circuit using Alligator Clips (optional). Do not touch the Clamp Meter, its Test Leads or any part of the Circuit while it is on. Refer to 「WARNING 4. Dangerous Voltage Measurement Procedure」 on page 13 to 15.

4. Read the voltage on LCD.
5. Hz and % : When measuring \bar{V} or \tilde{V} , press SHIFT Key to measure Hz and %.
6. Display Hold, Difference, Max/Min, Peak Hold (SK-7718 only) and Range Selection (SK-7719 only) are available. Refer to DH Key, DIFF Key, MAX/MIN Key, PH Key and RANGE Key on page 8 to 10.
7. When measurements are finished, remove Test Prods from the circuit and set FUNCTION Switch to OFF position.




Fig. 9

5-4. RESISTANCE (Ω) MEASUREMENTS

⚠ WARNING

Do not measure Voltage on Ω , \cdot , \cdot , \cdot position. This will cause shock hazard to the operator and damage to the instrument. In case in-circuit resistance is measured, turn off power to the circuit being measured and discharge all capacitors in the circuit.

Prior to measurements, read carefully 「4. SAFETY PRECAUTIONS」 of this instruction manual.

1. Insert Black Test Plug into COM Terminal and Red Test Plug into Ω , \cdot , \cdot , \cdot Terminal.
2. Set FUNCTION Switch to Ω , \cdot , \cdot , \cdot position.
3. If the resistor to be measured is connected in a circuit, turn off power to the circuit and discharge all capacitors in the circuit.
4. Open one side of the resistor to be measured and connect Test Prods to both sides of the resistor (or circuit).
5. Read the resistance on LCD.
6. Display Hold, Difference, Max/Min and Range Selection (SK-7719 only) are available. Refer to DH Key, DIFF Key, MAX/MIN Key, and RANGE Key on page 8 to 10.
7. When measurements are finished, remove Test Prods from the resistor (circuit) and set FUNCTION Switch to OFF position. Then restore the circuit as it was.




Fig. 10

5-5. CONTINUITY (\cdot) TESTS

⚠ WARNING

Do not measure Voltage on Ω , \cdot , \cdot , \cdot position. This will cause electrical shock hazard to the operator and/or damage to the instrument. In case continuity test is made, turn off power to the circuit being measured and discharge all capacitors in the circuit.

1. Insert Black Test Plug into COM Terminal and Red Test Plug into Ω , \cdot , \cdot , \cdot Terminal.
2. Set FUNCTION Switch to Ω , \cdot , \cdot , \cdot position.
3. Press SHIFT Key once to display \cdot symbol on LCD.
4. Turn off power to the circuit and discharge all capacitors in the circuit.
5. Connect Test Prods of Test Leads to the circuit to be tested. Buzzer sounds when the resistance value is less than approx. 50 Ω .

6. When measurements are finished, remove Test Prods from the circuit and set FUNCTION Switch to OFF position. Then restore the circuit as it was.




Fig. 11

5-6. DIODE (\cdot) TESTS

⚠ WARNING

Do not measure Voltage on Ω , \cdot , \cdot , \cdot position. If the diode is connected in a circuit, turn off power to the circuit and discharge all capacitors in the circuit. Disconnect one side of the diode and test it.

1. Insert Black Test Plug into COM Terminal and Red Test Plug into Ω \rightarrow . \rightarrow . \rightarrow Terminal.
2. Set FUNCTION Switch to Ω \rightarrow . \rightarrow . \rightarrow position.
3. Press SHIFT Key twice to display \rightarrow symbol on LCD.
4. If the diode is connected in a circuit, turn off power to the circuit and discharge all capacitors in the circuit and disconnect one side of diode from the circuit.
5. Connect Black Test Prod to Anode and Red Test Prod to Cathode of the diode being measured. This is Reverse Connection. Confirm that the LCD displays OL symbol. Refer to the figure 13.
6. Reverse Test Prod connection to the diode being tested. This is Forward Connection. In case of Silicon diodes, LCD displays 0.1V to 0.4V, and the diodes are judged good.
7. When measurements are finished, remove Test Prods from the diode and set FUNCTION Switch to OFF position.




Fig. 13

5-7. Capacitance (\rightarrow) MEASUREMENTS

⚠ WARNING

Do not measure Voltage on Ω \rightarrow . \rightarrow . \rightarrow position. This will cause electrical shock hazard to the operator and damage to the instrument. Before taking capacitance measurements, remove power to the circuit being measured and discharge all the capacitors in the circuit.

1. Insert Black Test Plug into COM Terminal and Red Test Plug into Ω \rightarrow . \rightarrow . \rightarrow Terminal.
2. Set Function Switch to Ω \rightarrow . \rightarrow . \rightarrow position.
3. Press SHIFT Key 3 times to display nF unit on LCD.
4. Press DIFF Key for more than 1 second to display 0 ± 1 digit on LCD only in case it shows more digits.
5. Remove power to the circuit being tested and discharge all capacitors in the circuit.
6. Open one side of the capacitor to be measured and connect Test Prods of Probe Tester to the capacitor.




Fig. 12

7. Read the capacitance on LCD.
 8. After measurements, set FUNCTION Switch to OFF position.
- NOTE:** High capacitance measurement takes longer time for testing.




Fig. 14

6. MAINTENANCE

6-1. WARRANTY STATEMENT

The warranty statement for the Clamp Meter is printed on the last page of the manual. Read it carefully before requesting a warranty repair.

6-2. BATTERY REPLACEMENT

⚠ WARNING

To prevent electrical shock hazard, remove both Test Leads from external circuit connections and from the Input Terminals before removing Rear Case to replace the batteries.

1. If the battery is consumed and BAT symbol is shown on LCD, replace the battery.
2. Remove both Test Leads from the circuit and from the Terminals.
3. Set FUNCTION Switch to OFF position.

4. Remove Rear Case unscrewing the 4 screws.
5. Take out the worn-out battery from Battery Case.
6. Place one fresh 9V 6F22 battery in Battery Case.
NOTE: If the battery is installed in the wrong polarity, the display will not be shown when FUNCTION Switch is turned on.
Do not leave the instrument in this condition as it results in battery consumption.
7. Replace Rear Case.
NOTE: If the instrument is taken out of service for an extended time, remove the battery from Battery Case and store separately.





Fig. 15

6-3. PERIODICAL CHECK AND CALIBRATION

Periodical check and calibration are necessary to make safety measurements as well as to maintain the specifications described on page 3 to 7.

It is recommended that the instrument may be checked and calibrated once each year and/or after it is repaired. Periodical Check and Calibration services are available at KAISE AUTHORIZED SERVICE AGENCY through your local dealer at a cost basis charge.

Pack the instrument securely in its original carton together with descriptions of your name, address, telephone number and the service required, and ship prepaid to your local dealer.

6-4. REPAIR

Repair service, warranty or non-warranty, is available at KAISE AUTHORIZED SERVICE AGENCY through your local dealer. Warranty repair is executed free of charge, but, non-warranty repair is charged on the cost basis.

Pack the instrument securely in its original carton together with descriptions of your name, address, telephone number, problem encountered and the service required, and ship prepaid to your local dealer.

When the instrument does not operate properly, the following steps should be taken before returning the instrument for repair, warranty or non-warranty.

WARRANTY

The Clamp Meters, SK-7718/7719 are warranted in its entirety against any defects of material or workmanship under normal use and service within a period of one year after the date of purchase of the instrument by the original purchaser. This warranty is extended by KAISE AUTHORIZED DEALER only to original purchaser or original user of the instrument on condition that the Warranty Registration Card is completed and returned to the authorized dealer within two weeks after the purchase of the instrument new from the dealer. The obligation under this warranty to be executed by KAISE AUTHORIZED DEALER is limited to repairing or replacing the Clamp Meters SK-7718/7719 returned intact to it, with transportation charge prepaid, and which to its satisfaction is judged by it to have been thus defective. KAISE AUTHORIZED DEALER and KAISE CORPORATION, the manufacturer shall not otherwise be liable for any damages or loss, consequential or otherwise. The foregoing warranty is exclusive and in lieu of all other warranties including any warranty of merchantability, whether expressed or implied.

This warranty shall not apply to any instrument or other article of equipment which shall have been repaired or altered outside KAISE AUTHORIZED SERVICE AGENCY, nor which has been subject to misuse, negligence or accident, incorrect wiring by users, or installation or use not in accord with instructions furnished by the manufacturer.

KAISE AUTHORIZED DEALER

| SYMPTOM | POSSIBLE CAUSE | NECESSARY STEPS |
|--|---|---|
| No Display. | Low Battery. | Replace the battery. (Refer to P28.) |
| | Battery is installed in the wrong polarity. | Install battery in the correct polarity. |
| Readings are not stable on all functions. | The contact of Plugs of Test Leads is bad. | Confirm the contact of Plugs. |
| | Influence of noise. | Use a suitable shield or keep away from noise. |
| FUNCTION Switch is set to desired position and LCD displays some value under no input being applied. | | If LCD displays less than 3 digits, continue the measurement. If LCD displays more than 4 digits and INITIALIZE is not performed exactly, press DIFF Key to display 0±1 digit on LCD and perform measurements. In this case, accurates measurements are ensured. |

MEMO