


## ET6189A

## ISUZU CRANKSHAFT STOPPER





- This crankshaft stopper is used to retain the flywheel when required to service the flywheel
  or balancer and related components, and when setting engine timing.
  - Once the starter is removed, this tool is installed in its place. The toothed adapter and required spacer are placed onto the center bolt of  $this\ tool$ , and the assembly is placed into the starter opening.
- The starter bolts/studs are used to retain the body of this tool, and the center bolt/nut are tightened once its teeth are engaged in the ring gear. Unapproved methods may damage the flywheel.
- Application: Isuzu
- **OEM** Equiv: 5-8840-2230-0 / EN-47680